

# Rover / ASM-X 10.1.9

## Legend

Existing Function

Currently Under Development

Functionality doesn't apply

ABS				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
ABS BOSCH (ZT - T / ROVER 75)				
ABS BOSCH 5.0				
ABS BOSCH 5.3				
AIRBAG (SRS)				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
ABG ACU3MK2 X70Ph3-000F-08				
<i>Special Functions</i>				
<i>Configuration Of System Components</i>				
<i>ECU Status</i>				
<i>Ignition Module Configuration</i>				
<i>Unlock Computer</i>				
<i>Write Date Of Last After Sales Operation</i>				
<i>Write of VIN</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
AIRBAG ACU3				
<i>Special Functions</i>				
<i>Control Unit Renewal</i>				
<i>Reconfigure Control Unit</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
AIRBAG ACU3 (CITY ROVER)				
<i>Special Functions</i>				
<i>Driver's Side Airbag</i>				
<i>Driver's Front Airbag</i>				
<i>Driver's Pretensioner</i>				
<i>Inhibit Key</i>				
<i>Passenger's Side Airbag</i>				
<i>Passenger's Front Airbag</i>				
<i>Passenger's Pretensioner</i>				
<i>Replace Electronic Control Unit (ECU)</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
AIRBAG EC5/RC5				
AIRBAG TEMIC MRS3 SRS DCU (ROVER 25/45/75)				
<i>Special Functions</i>				
<i>Airbag Initialisation (ROVER 25)</i>				
<i>Airbag Initialisation (ROVER 45)</i>				
<i>Airbag Initialisation (ROVER 75)</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
AIRBAG TEMIC MRS3 SRS DCU (ZT-T/ROVER 75)				
<i>Special Functions</i>				
<i>Airbag Initialisation (ROVER 25)</i>				
<i>Airbag Initialisation (ROVER 45)</i>				
<i>Airbag Initialisation (ROVER 75)</i>				
ANTI-THEFT ALARM				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
ALARMA 5AS 96MY				
<i>Special Functions</i>				
<i>Programming or Resynchronising P1ip</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
ALARMA 5AS 98MY				
<i>Special Functions</i>				
<i>Programming or Resynchronising P1ip</i>				

ECU	Trouble Codes	Live Data	Actuators	Special Functions
BCU GM6 - SECURITY (ZT-T ROVER 75)	✓	✓	✓	✓
<i>Special Functions</i>				
Remote Handset Programming				
Remote Handset Status				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
CCU - ROVER 600	👤	✓	✓	👤
SCU - SECURITY (ROVER 25)	👤	✓	✓	✓
<i>Special Functions</i>				
Alarm Test				
Alarm Trigger Store				
ECU Test				
EKA Programming				
Enter the VIN code				
REMOTE CONTROLS PROGRAMMING				
Replace Electronic Control Unit (ECU)				
AUTOMATIC GEARBOX				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
JATCO AUTOMATIC GEARBOX	✓	✓	✓	👤
CLIMATRONIC CONTROL				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
ATC (ZT-T / ROVER 75)	✓	✓	✓	✓
<i>Special Functions</i>				
Replace Electronic Control Unit (ECU)				
ELECTRIC SEATS				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
ELECTRIC SEATS AND MIRRORS (Rover 800)	👤	👤	👤	👤
ELECTRIC WINDOW WINDER				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
SCU - WINDOWS (ROVER 25)	👤	✓	👤	🚫
ELECTRONIC DASHBOARD				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
VDO INSTRUMENT PACK (ZT-T ROVER 75)	✓	✓	✓	✓
<i>Special Functions</i>				
Inspection				
Oil Service				
Time Service				
ENGINE ELECTRONICS (PETROL/DIESEL)				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
BOSCH EDC 1.3.1	✓	✓	✓	✓
<i>Special Functions</i>				
ECM/Security Re-Configuration (Freelander only)				
ECM/Security Re-Configuration (Range Rover P38 only)				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
DIESEL DDE 4.0	✓	✓	✓	✓
<i>Special Functions</i>				
Immobilisation Learn				
Injector Grade Compensation				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
Edc15 Injection	✓	✓	✓	✓
<i>Special Functions</i>				
Learn Security Code				
Security Line				
Security Status				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
EMS 2000 SIEMENS	✓	✓	✓	✓
<i>Special Functions</i>				
All Adaptions				
Dynamic Trim				
Idle Control				
Knock Sensor				
Mass Air Flow Sensor (MAF)				
Misfire				

Oxygen Sensor				
Stepper Reset				
Throttle Position				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
MEMS 1.6	✓	✓	✓	👤
MEMS 1.9	✓	✓	✓	✓
<i>Special Functions</i>				
Immobilizer Code Learning				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
MEMS 2J (PETROL)	✓	✓	✓	👤
MEMS 3	✓	✓	✓	✓
<i>Special Functions</i>				
Immobilisation Learn				
Reset All Adaptions to Defaults for New Engine				
Reset Closed Throttle Position				
Reset Flywheel Adaptions				
Reset Fuelling Adaptions				
Reset Idle Adaptions				
Set Service Ignition Offset				
<b>EXTERIOR LIGHTS</b>				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
LIGHT SWITCH (ZT-T / ROVER 75)	✓	✓	✓	👤
<b>FUEL BURNING HEATER</b>				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
FUEL BURNING HEATER (ZT-T / ROVER 75)	✓	✓	✓	✓
<i>Special Functions</i>				
Prime System				
Replace Electronic Control Unit (ECU)				
<b>HEATED SCREENS</b>				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
BCU GM6 - HEATED REAR WINDOWS (ZT-T / ROVER 75)	✓	🛑	✓	👤
<b>IMMOBILIZER</b>				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
IMMOBILIZER EWS2	✓	✓	🛑	✓
<i>Special Functions</i>				
Transponder-Key 1 Status				
Transponder-Key 10 Status				
Transponder-Key 2 Status				
Transponder-Key 3 Status				
Transponder-Key 4 Status				
Transponder-Key 5 Status				
Transponder-Key 6 Status				
Transponder-Key 7 Status				
Transponder-Key 8 Status				
Transponder-Key 9 Status				
<b>INTERCONNECTION UNIT</b>				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
CCU ALARMA 5AS 96MY	👤	🛑	🛑	✓
<i>Special Functions</i>				
Read EKA Code				
<b>INTERIOR LIGHTS</b>				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
BCU GM6 - INTERIOR LIGHTS (ZT-T / ROVER75)	✓	✓	✓	👤
SCU - LIGHTS (ROVER 25)	👤	✓	✓	🛑
<b>MULTIFUNCTION DISPLAY</b>				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
ALPINE BOARD MONITOR (Rover75/MGZT)	✓	✓	🛑	✓
<i>Special Functions</i>				
Autotest				
<b>NAVIGATION</b>				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
PHILLIPS NAVIGATION (Rover75/MGZT)	✓	✓	🛑	✓
<i>Special Functions</i>				

Autotest

**PARKING ASSISTANCE**

ECU	Trouble Codes	Live Data	Actuators	Special Functions
PARKING DISTANCE CONTROLLER (Rover75/MGZT)				

**PCM - POWERTRAIN CONTROL MODULE**

ECU	Trouble Codes	Live Data	Actuators	Special Functions
EEC V (GENERIC - ALL ENGINES)				

**POWER STEERING**

ECU	Trouble Codes	Live Data	Actuators	Special Functions
ELECTRIC POWER STEERING (EPAS)				

**RAIN / BRIGHTNESS SENSOR**

ECU	Trouble Codes	Live Data	Actuators	Special Functions
RAIN SENSOR (ZT-T / ROVER 75)				

**SUNROOF**

ECU	Trouble Codes	Live Data	Actuators	Special Functions
SUNROOF WEBASTO (ZT-T / ROVER 75)				

**VIDEO**

ECU	Trouble Codes	Live Data	Actuators	Special Functions
VIDEO MODULE LOWE OPTA (Rover75/MGZT)				

**WASHERS & WIPERS**

ECU	Trouble Codes	Live Data	Actuators	Special Functions
BCU GM6 - WASH AND WIPE (ZT-T / ROVER 75)				
SCU - WASH WIPE (ROVER 25)				